

## Bluebell Paging Spare Parts

BMB01	Master Base & PSU
IBBU01	Internal Master Battery Backup
BMB01-S	Slave Base
BMB01-R	Repeater & PSU
IBBU02	Internal Repeater Battery Backup
BLT01	System Logon Terminal
BMB01-P	Wireless Adaptor for NurseCall Paging
BPCSW	System monitor
BB01	Wireless Location Beacon
BMB01-U	Wireless I/O Interface
BWA01	Wireless Alarm Unit
BWA01-P	Alarm Pull Cord switch
BP01-SA	Staff Attack Pager
	Ripcord Lanyard and magnet
BRM01	5-Bay Pager Charging & PSU
BRS01	Single Charger and PSU
BSWP	Swipe Bracket with Encoded Label
BMB01-D	Display Interface & PSU
IBBU03	Internal Display Interface Battery Backup
BDC01-S	Display Controller & Sounder
BD01-M	Matrix Display & PSU