

Scope Spare Parts

CONX8E/1	Mains Transmitter
CONX8E/1MF	Mains Transmitter with Telephone I/F
GEO40A	40 Character Alpha Pager Vibrate, Holster AAA Battery
A821E	Standby 12V 0.8AH Battery/Charger
PageTeck2	12V 4-Zone - Non Prog
PageTeck2	12V 4-Zone - Programmable
PageTeck2	12V 8-Zone - Programmable
	Desk Display Pager
LUHFDP	Internal lightweight Di Pole Antenna with 5M lead
FDANT	External foled Di-Pole Antenna for difficult sites
FDWM	Wall mount Bracket
FEED5	5M feed cable
FEED10	10M feed cable
FEED15	15M feed cable